

Flat-Screen TV Wall Mount - Articulating - 22-55"

FPWARTB1M



*actual product may vary from photos

FR: Guide de l'utilisateur - fr.startech.com

DE: Bedienungsanleitung - de.startech.com

ES: Guía del usuario - es.startech.com

NL: Gebruiksaanwijzing - nl.startech.com

PT: Guia do usuário - pt.startech.com

IT: Guida per l'uso - it.startech.com

For the latest information, technical specifications, and support for this product, please visit www.starTech.com/FPWARTB1M.

Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

PHILLIPS® is a registered trademark of Phillips Screw Company in the United States or other countries.

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.



Warning statements

Make sure to assemble this product according to the instructions. Failure to do so might result in personal injury or property damage.

Make sure that the weight of the TV doesn't exceed the weight capacity of this product. If you exceed the weight capacity, you might experience personal injury or damage to the equipment. This product can support the following weight: Up to 3 fs. (77 lb.).

Never operate this product if parts are missing or damaged.

Wall structures vary, and it's important to make sure that the type of wall structure and mounting hardware that you're using will properly support the mounted equipment. Failure to do so may result in personal injury and/or equipment damage. The wall structure should be capable of supporting at least four times the weight of the mounted equipment.

The mounting hardware included with this product might not be adequate for some wall structures. If you keep the continued to the season of the continued to the season of the season of the continued to probe selection to that the wall mount or to provide specific mounting instructions for a continued to probe selection to that the wall mount or to provide specific mounting instructions for the continued to t

Varningsmeddelanden

Se till att du monterar produkten i enlighet med instruktionerna. Om du inte gör det kan skada på person eller egendom uppstå.

Se till att skärmens vikt inte överstiger produktens viktkapacitet. Om viktkapaciteten överstigs kan skada på person eller utrustning uppstå. Denna produkt har stöd för följande vikter: 35 kg. Använd aktrio produkten om delar saknas eller är skadade.

Eftersom väggstrukturer varierar är det vilktigt att kontrollera att väggstrukturen och monteringsutrustningen som du använder klarar av den monterade utrustningen. Om du inte gör det kan skada på person och feller utrustning uppstå. Väggstrukturen ska kunna klara av minst fyra gånger vikten av den monterade utrustningen.

Monteringsutrustningen som medföljer produkten kanske inte år lämplig för vissa väggstrukturer. Om du saknar nödvändliga kunskaper för att fästa denna produkt på väggstrukturen som du använder, kontakta en professionell konstruktör för att installera väggmonteringen eller för att ge specifika monteringisinstruktioner för din vägstruktur.

Avertissements

Assemblez ce produit conformément aux instructions. Si vous ne respectez pas ces instructions, vous risquez de vous blesser ou d'endommager l'équipement.

Vérifiez que le poids du moniteur ne dépasse pas la capacité pondérale du produit. Si vous dépassez la capacité pondérale, vous risquez des blessures corporelles ou des dommages matériels. Ce produit pour supporter de 3 & la ...

N'utilisez pas ce produit si des pièces sont endommagées ou manquantes.

Les structures des murs varient. Vous devez impérativement vérifier que le type de mur et le matériel de fination que vous utilisez permettent de soutienir correctement l'équipement. Dans le cas contraire, vous risquez des blessures corporelles ou des dommages matériels. La structure du mur doit pouvoir supporter au moins quatre fois le polds de l'équipement monté.

Le matériel de fixation inclus avec ce produit riest pas forcément approprié pour toutes les structures de mans. Si vous ne disposes pas des compétences necesaines pour intafaler ce produit au mur, contacte un professionnel afin qu'il install e le support mural ou qu'il vous fournisse les instructions de montage spécifiques à votre structure de mur.

Warnhinweise

Montieren Sie dieses Produkt gemäß den Anweisungen. Anderenfalls kann dies zu Verletzungen von Personen oder Schäden an Eigentum führen.

Das Gewicht des TVs darf die zulässige Traglast des Produkts nicht übersteigen. Wenn die Traglast überschritten wird, kann dies zu Verletzungen von Personen oder Schäden an Geräten führen. Dies Produkt ist für folgendes Gewicht geeignet: 35 kg.

Das Produkt darf nicht bedient werden, wenn Teile fehlen oder beschädigt sind.

Wandstrukturen unterscheiden sich, und es muss sichergestellt werden, dass die Wand und das verwendete Montagematerial das montierte Gerät halten kann. Anderenfalls kann dies zu Verletzunger von Personen und/doer Schäden an Geräten führen. Die Wand muss mindestens das Vierfache des Gewichts des montierten Geräts halten können.

Das mitgelieferte Montagematerial ist möglicherweise nicht für jede Wand geeignet. Wenn Ihnen die nötigen Fachkenntnisse zum Anbringen dieses Produkts an einer Wand fehlen, lassen Sie einen Fachmann den Wandhalter anbringen, oder lassen Sie sich von einem Fachmann Montageanweisunge für ihre Wand erteilen.

Dichiarazioni di avvertenza

Assemblare il prodotto rispettando le istruzioni. Il mancato rispetto delle istruzioni potrebbe causare danni a persone o proprietà.

Verificare che il peso del monitor non superi la capacità di supporto del prodotto. In caso di superameni della capacità di supporto potrebbero verificarsi danni a persone o apparecchiature. Il prodotto è in grado di supportare i seguenti pesì 23 kg.

Non utilizzare il prodotto in presenza di parti mancanti o danneggiate.

Le caratteristiche dei mui sono variabili ed è importante verificare che la struttura muraria e l'hardware di montaggio in usos siano in gado di supportare adequatamente le appraecchiature montate. Il mancato rispetto delle istruzioni potrebbe causare danni a persone o proprietà. La struttura muraria deve essere in grado di supportare un peso almeno quattro volte superiore a quello dell'appraecchiatura montata.

L'hardware di montaggio incluso con il prodotto potrebbe non essere adequato ad alcune trutture murarie. Se l'utente non dispone delle competerne necessarie per agganatare il prodotto alla struttur muraria in uso, dovrà contattare un professionista edile per installare il supporto a parete o ottenere istruzioni di montaggio per la struttura muraria in uso.

Mensagens de aviso

Certifique-se de que monta este produto de acordo com as instruções. O incumprimento pode resultar em ferimentos pessoais ou danos de propriedade.

Certifique-se de que o peso do monitor não excede a capacidade de peso deste produto. Se exceder a capacidade de peso, pode sofrer ferimentos pessoais ou danos no equipamento. Este produto pode suportar o seguinte peso: 35 kg.

Nunca opere este produto se faltarem peças ou estas estiverem danificadas

As estruturas de parede variam e é importante certificar-se de que o tipo de estrutura de parede e handware de montagem que está a usar irá suportar devidamente o equipamento montado. O incumprimento pode resultar em ferimentos pessoais e/ou dano se no equipamento. A estrutura de parede deve ser capaz de suportar pelo menos quatro vezes o peso do equipamento montado.

O hardware de montagem incluídos com este produto pode não ser adequado para algumas estruturas de parede. Se não tivor o conhecimento necessário para fixa este produto à estrutura de parede que está a usar, contacte um profissional de construção para fazer a instalação em parede ou para fornecer instruções de montagem específicas para a sua estrutura de parede.

Advertencias de uso

Asegúrese de ensamblar este producto según las instrucciones. De lo contrario, pueden producirse lesiones personales o daños en la propiedad.

Asegúrese de que el peso del monitor no exceda la capacidad de carga de este producto. Si se excede dicha capacidad se podrían producirse lesiones personales o daños al equipo. Este producto tiene la siguiente capacidad de carga: 35 kilogrames.

Nunca opere o ponga en funcionamiento este producto si faltan piezas o hay daños en las mismas.

Las estructuras de las paredes pueden variar y, por tanto, es importante determinar con certeza que el tipo de estructura de la pared y el hardware de montaje que se va a utilizar puedan soportar debidamente el equipo. De lo contrato, se puedem producir lesiones personales o daños en el mismo. La estructura de la pared debe ser capaz de soportar al menos cuatro veces el peso del componente instalación.

El hardware de montaje incluído con este producto puede no ser adecuado para algunas estructuras de pared. En o tiene le experiencia sufficiente para fije reste producto a la estructura de la pared correspondiente, póngase en contacto con un profesional de la construcción para instalar el soporte de pared o para que le proporcione las instrucciones específicas de montaje para su estructura de pared.

Waarschuwingen

Zorg dat dit product volgens de instructies in elkaar wordt gezet. Indien dit niet goed gebeurt kan lichamelijk letsel of materiële schade ontstaan.

Zorg dat het gewicht van het scherm de maximale capaciteit van dit product niet overschrijdt. Als u de gewichtscapaciteit overschrijdt, kan persoonlijk letsel of schade aan de apparatuur ontstaan. Dit product ondersteun

Gebruik dit product nooit als er onderdelen ontbreken of beschadigd zijn.

Omdat wanden verschillen, is het belangrijk dat u ervoor zorgt dat het type wandstructuur en de montagemiddelen die u gebruikt de gemonteerde apparatuur goed ondersteunen. Indien u dit niet doet kan lichamellijk letsel envol schade aan de apparatuur ontstaan. De wandstructuur moet voldoende zijn om ten minste vier keer het gewicht wan de gemonteerde apparatuur te ondersteunen.

De bij dit product geleverde montagemiddelen kunnen niet geschikt zijn voor sommige wandstructure Als u orwoldoende kennis helbt om dit product aan de door u gebruikte wandstructuur te bevestigen, neem dan contact op met een bouwkundige om de steun aan de muur te install eren of specifieke montage-instructies voor uw wandstructuur te geven.

注意

必ず取扱説明書に従って本製品の組み立てを行って下さい。取り扱いを誤った場合に、傷害を負う恐れ や物的指索が発生する恐れがあります。

取り付けるモニターの重量が、本製品で定められた最大積載重量を超えないようにして下さい。最大積 載重量をオーバーした場合、傷害を負う恐れやモニターや本製品に損害が発生する恐れがあります。 本製品は、最大38kまでのモニター重量に対抗にています。

本製品で使用している部品の一部が紛失していたり損傷している状態で使用するのは絶対に止 めて下すい

壁の構造はお客様の環境でとに異なります。ご使用になる壁の構造タイプと取付け金具が、取り付け モニターを確実に支持するごとを確認して下さい。確認を怨った場合、傷害を負う恐れや物的損害が 発生する恐れがあります。壁の構造が、取り付けるモニター重量の最低 4 倍まで支持できるだけの強 なを持っていなければかはません。

本製品に同梱されている取付け金具は、ご使用になる壁の構造に対して十分ではない場合があります。本製品を壁間に取り付ける時、十分な専門知識が不足していると判断された場合、専門業者に連絡を設って、本製品の取り付けを行ってもらうか、お客様の壁の構造に適した取り付け方法を教えてもらったから取り付けを行ってより、



Table of Contents

Warnings	i
Technical specifications	1
Package contents	2
Requirements	5
Installation	6
Prepare FPWARTB1M for mounting	6
Attach the wall mount to the wall	7
Reattach the decorative covers	8
Assemble the TV mount	9
Mount a TV with a flush mounting surface	12
Mount a TV with a recessed mounting surface	13
Attach the TV to the wall mount	15
Route the cables	16
Adjust the tilt and swivel angle of the TV	17
Technical support	18
Manus atu infansation	10




Technical specifications

Unless otherwise indicated, the technical specifications in the table below apply to the TV or display.

Type of measurement	Measurement
VESA mounting hole pattern on the TV mount	100x100 100x150 200x100 200x200 300x200 300x300 400x200 400x300 400x400
Weight capacity of TV mount	35 kg (77 lb.)
Tilt	+2º to -12º
Screen size	Between 559 mm and 1397 mm (22″ and 55″)
Swivel	+90º to -90º

Package contents





VESA extension brackets Qty: Four



Wrench Qty: One



Bracket screws Qty: Four





Nuts Qty: Four



M5x14 mm screws Qty: Four











Small spacers Qty: Eight

Large spacers Qty: Eight









Screws Qty: Four







Bracket washers Qty: Four



Instruction manual Qty: One

B

Requirements

- A display or TV that is compatible with one of the VESA mounting hole patterns FPWARTB1M supports
- · A Phillips screwdriver

Requirements are subject to change. For the latest requirements, please visit www.StarTech.com/FPWARTB1M.




Installation

Prepare FPWARTB1M for mounting

- 1. Remove the center decorative cover from the wall mount.
- 2. Remove the top and bottom decorative covers from the wall mount.
- 3. Use the wrench provided to remove one bolt from the front of the wall mount and slide the TV mount up and away from the wall mount. (figure 1)

fiaure 1



Hard-to-find made easu


Attach the wall mount to the wall

Warning! Wall structures vary, and it is important that you make sure that the type of structure and mounting hardware that you are using will properly support the mounted equipment. Failure to do so may result in personal injury and/or equipment damage. The wall structure should be capable of supporting at least four times the weight of the mounted equipment.

Warning! The mounting hardware included with this product might not be adequate for some wall structures. If you lack the necessary expertise to attach this product to the wall that you are using, contact a construction professional to install the FPWARTB1M or to provide specific mounting instructions for your wall structure.


- Position the wall mount so that the arrow on the TV mount is facing upwards, and use the holes in the ends of the mounting bracket as a template to mark the location on the wall where you want to attach the wall mount. (figure 2)
- 2. Follow the appropriate steps for the type of wall that you're using and attach the **wall mount** to the wall.

figure 2



Reattach the decorative covers

- 1. When the wall mount is attached to the wall, snap the top and bottom decorative covers back onto the wall mount.
- 2. Snap the center decorative cover onto the wall mount.(figure 3)





Hard-to-find made easu®


Assemble the TV mount

If the mounting holes on the **TV mount** aren't compatible with the mounting holes on your TV or display, you can use the **VESA mount extensions** to create a compatible mounting hole configuration.


You can position the **VESA mount extensions** in the following three configurations:
















Mount a TV with a flush mounting surface


To accommodate different TV designs, the FPWARTB1M comes with five sets of screws of different lengths and diameters, two sizes of washers, and two sizes of spacers.

- 1. To select the combination of mounting hardware that you need to use to attach the VESA mount extensions to the TV, complete the following:
 - · Determine the depth of the mounting holes on the TV.
 - · Determine the diameter of the mounting holes on the TV.

Note: If you're using a TV with a flush mounting surface, you don't need to use any of the provided spacers.

- 2. Position the end of the TV mount with the circle closest to the top edge of the TV.
- Line up the TV mount or the VESA mount extensions with the mounting holes on the back of the TV.
- 4. Place the small washers or large washers over the TV mount or the VESA mount extensions.
- Insert the M5x14 mm screws or the M6x14 mm screws through the washers, TV mount or VESA mount extensions, and into the back of the TV.
- 6. Use a Phillips screwdriver to tighten the screws. (figure 4)


Warning! Do not over-tighten the screws. If you encounter resistance while you're tightening the screws, stop tightening. Failure to do so could result in damage to the TV.



Mount a TV with a recessed mounting surface


To accommodate different TV designs, the FPWARTB1M comes with five sets of screws of different lengths and diameters, two sizes of washers, and two sizes of spacers.

- To select the combination of mounting hardware that you need to use to attach the TV mount or the VESA mount extensions to the TV, complete the following:
 - Determine the depth of the mounting holes on the TV.
 - Determine the diameter of the mounting holes on the TV.
 - Consult the images below to see the different hardware combinations available, and select the one that works best with your TV.



- 2. Position the end of the TV mount with the circle closest to the top edge of the TV.
- 3. Line up the TV mount or the VESA mount extensions with the mounting holes on the back of the TV.
- 4. Place the small or large washers over the TV mount or the VESA mount extensions.
- Insert the M6x30 mm screws, M8x30 mm screws, or M8x50 screws through the washers, TV mount or VESA mount extensions, spacers, and into the back of the TV.
- 6. Use a Phillips screwdriver to tighten the screws. (figure 5)

Warning! Do not over-tighten the screws. If you encounter resistance while you're tightening the screws, stop tightening. Failure to do so could result in damage to the TV.




Attach the TV to the wall mount

Warning! Make sure that the weight of the TV doesn't exceed the weight capacity of this product. If you exceed the weight capacity, you might experience personal injury or damage to the product. This product can support the following weight: Up to 35 kg (77 lb.)

Warning! Attaching the TV is a two-person job. Do not attempt to complete this task by yourself.

- Carefully slide the TV mount onto the mount attachment at the end of the wall mount.
- 2. Take the bolt that you removed earlier and insert it into the **wall mount** and **TV mount**.
- 3. Use the provided **wrench** to tighten the bolt. (*figure 6*) *figure 6*






Route the cables

- 1. Remove the decorative covers from the arms of the wall mount.
- 2. Position the cables in the decorative covers and reattach them to the arms of the wall mount. (figure 7)


figure 7



Adjust the tilt and swivel angle of the TV

- 1. Use the provided wrench to loosen the bolts in the side of the TV mount.
- 2. Position the TV at the angle that you want.
- 3. Use the provided wrench to tighten the bolts in the side of the TV mount. (figure 8)

figure 8



Technical support

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit www.startech.com/downloads

Warranty information

This product is backed by a two-year warranty.

StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

Limitation of liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.





Hard-to-find made easy. At StarTech.com, that isn't a slogan. It's a promise.

StarTech.com is your one-stop source for every connectivity part you need. From the latest technology to legacy products — and all the parts that bridge the old and new — we can help you find the parts that connect your solutions.

We make it easy to locate the parts, and we quickly deliver them wherever they need to go. Just talk to one of our tech advisors or visit our website. You'll be connected to the products you need in no time.

Visit www.startech.com for complete information on all StarTech.com products and to access exclusive resources and time-saving tools.

StarTech.com is an ISO 9001 Registered manufacturer of connectivity and technology parts. StarTech.com was founded in 1985 and has operations in the United States, Canada, the United Kingdom and Taiwan servicing a worldwide market.